


Operating Instructions for Popcorn Machine

Please read and follow the instructions carefully.

POPCORN MACHINE CONTROLS:

The following controls are located on the top-front side of the popcorn machine:

1. **Warming Light Switch** – turns on the warming lamp light
2. **Kettle Motor Switch** – turns on the motor of the unit
3. **Kettle Heat Switch** – turns on the heating element of the kettle



INSTRUCTIONS:

1. Ensure the popcorn machine with cart are sitting on stable ground/surface.
2. Connect the popcorn machine to a 110v power outlet.
3. Turn Warming Light, Kettle Motor and Kettle Heat switches "ON" Allow the kettle to warm for 60-90 seconds. **WARNING:** The kettle becomes extremely hot very quickly. **DO NOT** touch the kettle.

	<p style="text-align: center;">⚠ WARNING</p> <p>To avoid burns, do NOT touch the kettle or any heated surface. Do NOT place or leave objects in contact with heated surfaces.</p> <p style="text-align: right;">013PW1112</p>
--	--

4. Now that the kettle is hot, add the oil, kernels and seasoning from the Naks Pak. The first batch will take approximately 4min to pop completely.
5. Dump the kettle when there's 4-5 seconds between pops. Using the kettle handle, dump the remaining kettle contents in the cabinet.
6. Repeat step 4 and 5 to make additional batches of popcorn as desired. If you're pausing in between batches or done making popcorn, turn kettle motor and heat switches off.
IMPORTANT! Keep the kettle switch "OFF" when you are not popping.
7. Once you're done using the popcorn machine, ensure the warming light, kettle motor and kettle heat switches are turned off and unplug the machine from the power outlet. **CAUTION:** The kettle may still be very hot. **DO NOT** touch the kettle.